



GM335 User Manual

Dear user:

Thank you for choosing our company's product! In order for you to fully enjoy the product, detailed usage instructions is provided below. Please read them carefully before using this product.

Warranty

- 1.The warranty period is 18 months from the date of purchase.
- 2.Within the warranty period, replacements and returns are guaranteed in case of product failure due to electrical circuit problems.

The warranty does not cover the following types of damages:
 - Man-made damages, such as disassembly, hard-surface impacts, submersion into water, use of improper current or voltage, lack of proof of purchase.
 - Damages caused by natural disasters, such as earthquakes, fires or floods.

- 3.Consumable parts (such as foot pads) and replacement spare parts are not included in our warranty.

OS Support and Performance Parameters

- 1.Standard 104-key mechanical keyboard compatible with WinXP/Win7/Win8/Win10/Mac OS10 systems and workstations.
- 2.USB2.0 gaming keyboard, in line with USB2.0 specification, compatible with USB2.0, USB1.1 devices, support plug and play.
- 3.Supply voltage: 5V DC
 Max operating current: <350mA
- 4.USB wired mode:N-key rollover (NKRO)
 Wireless mode:6KRO

Installation Notes

When using the keyboard for the first time, please insert the USB cable interface of the keyboard into the USB interface of the computer, the computer system will automatically detect the USB device, and it can be used normally after installing the driver by itself.

Function Description

1.Switch between wired mode and 2.4G wireless mode: There is a mode switch on the back of the keyboard, turn it to the left for wired mode, and turn it to the right for wireless mode.

2.2.4G wireless mode code matching operation: Please set the keyboard to wireless mode, press and hold the "FN+Right Ctrl" key for 3 seconds, the third indicator light in the upper right corner of the keyboard flashes green, indicating that it has entered the wireless code matching state. At this time, please insert the wireless receiver into the USB port of the computer, and the indicator light stops flashing within 1-3 seconds, indicating that the code is successfully paired.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1)This device may not cause harmful interference.
 (2)This device must accept any interference received, including interference that may cause undesired operation.
 Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
 Note: This equipment has been tested and found to comply with the limits for a class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
 This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 * Reorient or relocate the receiving antenna.
 * Increase the separation between the equipment and receiver.
 * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 * Consult the dealer or an experienced radio/TV technician for help.

Special Function Keys

Special Function Keys			
FN+F1	Media Player	FN+F6	Mute
FN+F2	Play/Pause	FN+Win	Lock/Unlock Windows
FN+F3	Stop	FN+ESC	Turn off keyboard backlight
FN+F4	Volume+	FN+DEL	Keep pressing 3 seconds to restore factory state
FN+F5	Volume-		
FN+ "↑"	Enhance backlight brightness		
FN+ "↓"	Weaken backlight brightness		
FN+ "←"	Lower backlight speed		
FN+ "→"	Increase backlight speed		
FN+PrtSc	Switch backlight effect (keyboard lighting effect has memory function)		
FN+PAUSE	Enter the keyboard to customize the default 6 groups of custom backlights, each time you press "FN+PAUSE" to switch a default lighting effect		
FN+ScrLk	Press "FN+ScrLk" to modify the current default custom lighting effect. After resetting the custom lighting effect, press "FN+ScrLk" again to save the current custom lighting.		

After Sales Support

If you have any questions when using our products, please contact us on Amazon or visit our website to leave a message: <https://www.newmen.com.cn/contact-en.php>